Dustcheck

Part of Absolent Air Care Group



| CFC Series |

Original Operating Instructions

Table of Contents

1. **Welcome** 3
    1.1. **How to use this manual** 3
    1.2. **Safety** 3
    1.3. **Regulatory Information** 4
2. **Installation** 8
    2.1. **Delivery** 8
    2.2. **Handling** 8
    2.3. **Assembly** 9
3. **Operation** 10
    3.1. **Start Up and Stopping** 10
    3.2. **Air Volumes** 10
4. **Absolute (HEPA) Filters (Where fitted)** 11
    4.1. **Installation** 11
    4.2. **Operation** 11
5. **Electrical Information** 12
    5.1. **Antistatic Medias and Earthing** 12
6. **Commissioning** 13
7. **Maintenance & Troubleshooting** 14
    7.1. **Inspections** 14
    7.2. **Troubleshooting** 15
    7.3. **Spare and Replacement Parts** 15
8. **Declaration of Conformity** 16

1. Welcome

Welcome to the user manual for your Dustcheck product! Thank you for choosing us. Original instructions are in English, all other languages are translations of this.

1.1. How to use this manual

This manual has been designed to be comprehensive, covering the Dustcheck branded **CFC Filter** Series.

The following introduction provides essential information concerning safety and regulatory requirements - **please ensure that these are read and understood prior to use.** The closing pages of the manual contain customer support details, a glossary and an index to aid navigation and understanding.

Where applicable, a collection of bespoke documents (e.g., drawings, specification(s), data sheet(s), commissioning report(s)), may be provided alongside this manual - if so, please ensure that the manual is read in conjunction with them.

If in any doubt, please contact Filtermist Limited by calling (+44) (0)1952 290500 or emailing sales@filtermist.com. Please read this manual carefully before using the product and it keep it on file for future reference.

1.2. Safety

Ensure that, at all times, competent people are involved with the installation, operation and maintenance of your product - **NEVER** allow untrained or unauthorised personnel to handle equipment.

Prior to putting the product into service, ensure that a thorough **risk assessment** is carried out. All aspects of the equipment and its usage - including routine operation, emptying, cleaning, maintenance, access, control function and activation - must be assessed for health and safety risks. Furthermore, protective measures, visible warnings and user training must have been implemented before operation is allowed, to reduce these risks to a safe level. The unit should only be put into service if the assessment confirms it is safe to do so.

Your product is specifically designed for the handling of dry dusts in air and must not be used for any other purpose - this is particularly true for combustible dusts. Any changes to the process and/or dust being handled should be assessed to ensure that no additional hazard is introduced and that control over the contaminant is not compromised. If sufficient information concerning application has not been imparted to us, there will be no statement of product or application and thus the installer/user **MUST** ensure that the equipment is suitable for purpose before putting into use.



DANGER! certain dusts are dangerous to handle (e.g., explosive, carcinogenic, toxic or statically charged in nature). The mixing of different dusts within the same extraction filter unit should only be done with the express consent of the filter unit supplier as the mixing of apparently innocuous dusts can in certain cases cause a potentially serious hazard.

Where **product discharge points** are fitted with rotary valves, screw conveyors or other powered moving parts, it may not be possible to fit guards which fulfill health and safety requirements due to restriction of product flow, specified physical parameters and the extent of our scope of supply. Wherever possible, it is recommended that guards with interlocks be introduced into the control systems such that personnel cannot gain access to a danger zone without the sources of power to the moving parts automatically being isolated.



IMPORTANT! Removable covers, bins, containers (or similar) which are removable without the aid of a tool, and which give access to a Danger Zone, must have safeguards providing adequate protection for the user/operator.

1.3. Regulatory Information

Your product must be used in compliance with the following regulations. COSHH and Pressure Equipment regulations apply to all products; LEV and ATEX/DSEAR regulations only apply in certain cases - see below for detail.

1.3.1 COSHH Regulations

All products must be used in accordance with **COSHH (Control of Substances Hazardous to Health)** regulations. In particular, please refer to the current **Health and Safety Executive (HSE)** guidance notes **EH40/2005 Workplace exposure limits (ISBN 9780717667031) and EH44 Dust in the workplace: General principles of protection**. These documents are available at **www.hse.gov.uk.**

As a minimum requirement under COSHH, **dust collectors must be inspected and tested at least once every 14 months** or in accordance with the specified schedules. Suitable records of examination, tests and subsequent repairs must be maintained and be kept available for inspection for a minimum period of 5 years.

1.3.2 LEV Regulations

Where your product forms part of a Local Exhaust Ventilation (LEV) system, you have additional duties to ensure that the LEV provides control over the contaminant. The LEV should be subject to a **Thorough Examination and Test (TExT)** at intervals not exceeding 14 months, though some LEVs have shorter intervals.

1.3.3 Pressure System Regulations

Where units are connected to a compressed air supply exceeding 0.5bar, the compressed air manifold has been designed and manufactured to comply with the requirements of the **Pressure Equipment (Safety) Regulations 2016** of the United Kingdom and the **Pressure Equipment Directive (2014/68/EU)** of the European Union. Please maintain pressure equipment, including the compressed air lines which connect to the compressed air header tank, in accordance with this legislation.

Compressed gas manifold(s) are supplied in accordance with the above legislation. Relevant information for safe operation is included on the nameplate attached to the manifold - please ensure that these limits are not exceeded. The presence of **N/A** in any box indicates that this specific information either need not, or must not, be given in order for manifolds in the stated category to comply with regulations. Where a test pressure is given, this may be on the basis of a sample testing routine and does not indicate that each individual manifold has been tested.

When connected to a pressure system, a reverse air dust collector is regarded as a part of that system and should be maintained and inspected as required by current legislation. A pressure relief valve will be required if the maximum operating pressure can be exceeded with the supply.

1.3.4 ATEX/DSEAR Regulations and Explosion Management

Explosion prevention and management is covered by European Union **ATEX Directive 2014/34/EU** and by United Kingdom **Dangerous Substances and Explosive Atmospheres Regulations (DSEAR).**

If your product is ATEX rated and/or presents a significant explosion risk, please read this information carefully - if it is not, you may proceed to the Installation section (below).

The ATEX Directives relate to all equipment intended for use in potentially explosive atmospheres. An explosive atmosphere is defined as a mixture of dangerous substances with air, under atmospheric conditions, in the form of gases, vapours, mist or dust in which, after ignition has occurred, combustion spreads to the entire unburned mixture. With regards to dust extraction, this definition generally applies to all equipment handling potentially combustible dust, gas or hybrid mixtures, or equipment located in areas where the equipment is operating within a potentially explosive atmosphere

Regulatory Compliance - what has to be done?

The following actions should be taken to comply with ATEX and DSEAR regulations:

- All sites should be assessed for potentially explosive atmospheres and be classified into zones, which should be clearly marked.
- All equipment intended to be used within a potentially explosive atmosphere should meet all the Essential Health and Safety Requirements of the Directive before being put into service.
- The user should operate the equipment in accordance with the user instructions supplied for the equipment. In the case of our products, the quotation outlines the scope of supply and forms part of the user instruction.
- The user should carry out a risk assessment for the system to ensure that no new risks are introduced if components and assemblies are combined. Any additional items of equipment supplied by the user (out of the scope of our supply) should be risk assessed and confirmed suitable prior to putting into service. This is particularly important when considering if the items have or can generate ignition sources, or when the unit forms part of a system.



WARNING! With potentially explosive dusts it is vital that all areas, and in particular areas around any explosion vents, are dust free to minimise the risk of secondary explosion in the event of primary explosion within the equipment.

Ignition Sources

The assessment of effective ignition sources will be based upon atmospheric characteristics such as **Minimum Ignition Energy (MIE)** and layer and cloud ignition temperature. The values used for the assessment will be contained within the quotation.



IMPORTANT! Ensure that these values are in line with the actual atmosphere present.

Do not introduce novel effective ignition sources during the installation of your product or during the combining of other equipment to form an assembly. No consideration has been made for ignition sources other than those pertaining directly to your equipment.

Where flammable gas/vapours exist alongside dust that has a high electrical resistivity cone, discharges can occur in bulk material (e.g., in the collection bin or hopper). In most such cases, the equipment is provided with some form of explosion protection and the filter unit is supplied with a product discharge option (e.g., bin or rotary valve). Where a rotary valve or screw conveyor is used on the discharge, ensure no metal pieces can enter the collector and get trapped leading to heat spots.

If a unit does not include any product discharge we generally do not supply explosion protection - in these instances a risk assessment should be carried out to determine if explosion protection is required and if so ensure that this is fitted. Certain potential ignition sources (e.g., stray electrical currents, ultrasonics, lightning) are site specific and should be risk assessed prior to installation. Always ensure that any electrical wiring used is suitable for the product classification.



IMPORTANT! Some materials can exhibit exothermic reactions including self-ignition of dusts. If the materials handled exhibit these characteristics, frequently remove collected material from the bin to avoid this becoming an effective ignition source.

Temperature Range

The operating temperature of the equipment can have a bearing on the specification. As such, it is important that the equipment is not operated in applications where the operating temperature is outside the range for which the equipment is specified.

General

In accordance with legislation, any dust collector or collection system handling potentially explosive product(s) should be fitted with explosion relief and/or suppression or be capable of explosion containment.

Units fitted with explosion relief must always be adequately secured / bolted down to prevent overturning during an explosion. National Building Specification (NBS) regulation BS EN 14491:2012 Dust Explosion Venting Protec- tive Systems provides guidance on the forces generated during an explosion to aid this securing. Equipment that is in compliance with the relevant ATEX directive will have clear markings indicating the category classification of the equipment. Only operate the equipment in areas it is suitable for.

Where explosion protection is incorporated into the equipment or vessel the filter unit is coupled to, you should ensure that the explosion pressure generated does not exceed the strength of the equipment. Explosion venting panels, where fitted, have been sized according to the latest guidance accounting for atmospheric characteristics. It is essential that these characteristics are correct for the product being handled (these are detailed in the quotation).

Where the filter unit does not have a product discharge fitted such as in the case of a silo vent filter, explosion protection is generally not supplied. This is because the volume of the vessel that the filter unit is connected to usually far out weighs the ‘dirty air’ volume of the filter unit. In these instances, to protect the assembly, adequate explosion protection should be provided to the vessel that the filter unit is mounted to, and not to the filter unit.

Antistatic Features

All metal components must be connected to a suitable and reliable earth. Where there is risk of static build up on filter media - which could lead to an electrostatic discharge capable of igniting the atmosphere - anti-static media will be selected and fitted. A suitable earth path will be present to the supplied earth boss – continued safety is only ensured by using the correct media.

TIP! It is recommended that checks for suitable earth are carried out at regular intervals.

IMPORTANT! When installing explosion prevention equipment, due consideration should be given to ensure adequate earth bonding to prevent static build up, which could create sparks that might result in the ignition of explosive mixtures of the dust and air.

The Connection of Ductwork

Explosion protection is generally not required in the ductwork. However, if an explosion occurs in the connected filter unit, flame and pressure can propagate into the ducting and travel for long distances. It is important that this effect is considered and if deemed unacceptable, a device should be installed in the ductwork to reduce or eliminate it. Ducting should be suitable for the application and selected to avoid the possibility of introducing ignition sources into the filter. Special consideration should be given to avoiding propagating discharges where painted (insulating) ducting is used - this also includes the use of flexible non-metallic hose. If metal ducting is selected it should also be connected to a suitable reliable earth.

TIP! Regular checks should be made to ensure that explosive dust is not allowed to build up in the ductwork and create concentrations within explosible limits. Where dampers are fitted, they should be adjusted slowly to avoid sparks.

Inspection and Maintenance

Equipment should be maintained in good condition and all safety features regularly inspected. Fixings and retaining devices, in particular those pertaining to items such as access doors and covers which could become dislodged in the event of an explosion, must be kept in good condition and must always be correctly replaced or refitted if removed. See the **Maintenance** section in this manual for further guidance.

2. Installation

This chapter provides information regarding the delivery, handling and installation of your product.

NOTE! When a reference is made here to "units", this can include sections of units as well as complete and fully assembled units.

2.1. Delivery

The majority of units are delivered to enable unloading by forklift. Units are loaded on pallets or skids to ease loading and unloading only - the presence of a pallet does **NOT** imply that the load will be inherently stable and suitable for forklift transportation. Indeed, great care should be taken when handling all units delivered on pallets, especially where their size/shape indicate that the centre of gravity may be high or offset from the centre line of the pallet. The unit should be lifted off the delivery vehicle and immediately lowered to the ground. If the unit is to be transported by forklift on the pallet the forks must be spread to the maximum possible width. The route taken must be over smooth, level ground and a low speed should be maintained. Lifting points for cranage may not have been included.

IMPORTANT! If a warning label regarding stability is attached to the unit this MUST NOT be ignored and should not be removed until the unit is removed from its pallet or stabilised in some other manner.

Units are delivered on blocks specifically to ease loading and unloading by forklift. When using a forklift to unload be aware that the unit may have no base and/or that easily damaged items may be located within the unprotected base. Where appropriate, extra long forks or fork extensions must be used to ensure that the base area of the unit is spanned.

2.2. Handling

All handling activities should be carried out by a competent person, in accordance with statutory regulations and any site or company-specific requirements. Do not attempt to lift a unit by other means than those recommended here.

Some of our products can be handled manually. When doing so, ensure that the correct techniques are used and if suitable hand holds are not available that handles, straps or slings are attached. The majority of units can be lifted from above, but if the unit is not fitted with lifting points you should contact us to confirm that your proposed lifting method is acceptable.

When lifting, always be aware that the cleaning valves and controller are very susceptible to damage; even a light impact which does no visible damage can cause slight deformation of a solenoid operator, which may result in non-operation. Lifting equipment can be attached directly to the bolt holes in the flanges, should they be present on your model - it maybe necessary to remove individual bolts to allow attachment.

WARNING! Do not remove more bolts than necessary and do not lift with bolts missing as this may weaken the structure.

IMPORTANT! Great care should be taken to ensure that slings cannot slip and that the manifold with cleaning valves or jet tubes are not used as a sling point.

Where a unit is to be assembled to other equipment, or where a unit is delivered in sections, ensure that the unit is positioned directly over the mating flange of the item onto which it is to be mounted and that locating rods or bars are inserted into corresponding holes in the mating flanges, down which the unit can slide as it is lowered. This ensures that a true alignment is achieved and that, if the last few centimetres are a drop rather than a controlled lowering, the stability and location of the unit is guaranteed.

2.3. Assembly

The majority of products do not have specific instructions for assembly. However, please be advised that when assembling split units or mating collectors to another plant, an appropriate sealant must be used on all joints to ensure an airtight seal adequate for the operating pressures. Two beads of sealant should be used on either side of the bolt hole (Figure 1). When assembling or disassembling split unit sections, care should be taken to ensure that the unit is re-assembled, sealed and clamped as it was originally supplied in order to maintain earthing continuity.

Furthermore, where a collector is floor mounted, it is necessary to ensure that the floor is level - otherwise the function of the bin mechanism could be adversely affected.



3. Operation

This chapter provides operational information for your product. It covers **Start Up and Stopping procedures**, **Air Volumes, Collection Bins, Adjustment of the Cleaning Cycle** and operation of the **Flameless Vent Valve.**

If your product is mounted on a silo, please ensure that the silo is not overfilled as this can cause blinding and over pressurisation. Transfer from lorry tanker to a vessel or silo must be correctly controlled to ensure that excessive volumes of air are not introduced into the vessel or silo - this can cause premature deterioration of the media.

Mixing venting filters are designed to operate in conjunction with the mixer operating cycle and need to be linked with its controls. When the mixer is being fed with product, the fan needs to be operating (i.e. linked with conveyor or skip controls), but when the mixer feed system stops the fan must be switched off. The cleaning controller should then be switched on and run for a maximum of two minutes; we suggest a timer is fitted to control this feature unless the mixer operation is no longer than two minutes. After the cleaning controller is switched off it should be reset and ready to start again.

3.1. Start Up and Stopping

Ensure air and power supplies are as specified. On initial start up, the air should be gradually increased to full duty over a period of hours and the system checked to ensure that the design duty is not exceeded - this causes increased filtration velocity which can give premature deterioration of the media.

Starting sequence:

1. Turn on compressed air and check pressure.
2. Switch on cleaning system (where fitted).
3. Switch on fan sets (where fitted).
4. Start system requiring dust filtration.

Stopping Sequence:

1. Stop the connected system requiring dust filtration.
2. Stop fan sets (where fitted).
3. Switch off cleaning system.

IMPORTANT! The operator should take care when operating this machine and mitigate or eliminate any risks in accordance with clause 7.11 of EN60335-2-69.

WARNING! The operator should wear appropriate hearing protection when operating this unit. The exact decibels can be found on the rating plate for the fan.

3.2. Air Volumes

In terms of air volume, equipment should be dampered down to run at a maximum of **75% design duty for 8 hours** with normal levels of dust loading for the system. If a dust collector is not fitted with a main volume control damper, it is strongly recommended that such a damper be fitted in the duct system to allow adjustment of air volume; systems without any form of volume control may allow the passage of excessive volumes of air which can have detrimental operational effects. **Always ensure that the equipment does not exceed the specified air volume.**

4. Absolute (HEPA) Filters (Where fitted)

If your product contains an Absolute (HEPA) filter section please read the following information carefully.

4.1. Installation

While installing an Absolute filter section, care must always be taken not to damage the filter media, as this can cause failure. Following installation, you should inspect the access door(s) to the section and ensure that they are tightly secured. Then, ensure that all door seals are in good condition and ensure that the filter element(s) themselves are securely clamped in position, with the seal on the elements correctly positioned against the sealing face.

4.2. Operation

Normal operating differential pressures with a new element are in the range of **12mm.wg** to **25mm.wg.** Elements will normally require changing at approximately **60mm.wg**. When replacing elements, always ensure that the correct specification is used and while doing so wear appropriate PPE. Always ensure correct sealing: never use a damaged or defective element. Absolute filters must never be run without the elements fitted.

5. Electrical Information

To ensure the safety of personnel and the integrity of the equipment, it is mandatory to refer to the manufacturer's wiring diagrams and operating instructions for each electrical component prior to and during the installation process. All work must be executed in strict accordance with local electrical guidelines and laws to maintain regulatory compliance and operational warranty. Failure to follow the specific schematics and safety protocols provided by the manufacturer may result in hazardous malfunctions or system failure.

WARNING! ALL ELECTRICAL INSTALLATION AND MAINTENANCE WORK MUST BE CARRIED OUT BY A COMPETENT ELECTRICAL PROFESSIONAL

5.1. Antistatic Medias and Earthing

Anti-static cartridges will have an earth path built into the cartridge and through the fixings to the filter plate. Your unit will be provided with an earth point - this should be connected to a suitable earth to prevent the build-up of high static charges, which may lead to discharges and possible ignition sources to explosive atmospheres.

Filter bags are connected to earth through the media, making contact with the cages and filter plate - this also requires the earth connection on the unit to be connected to a suitable earth.

All units fitted with anti-static medias should be appropriately earthed/grounded otherwise the anti-static properties may be negated.

TIP! Regular checks should be made to ensure the path to earth has not deteriorated.

IMPORTANT! Unless the specification of the process has been changed meaning it is no longer is necessary for anti-static media to be used, it is ex- tremely important to ensure that replacement elements are correctly specified and contain anti-static media.

IMPORTANT! When fitting new anti-static elements, ensure that prior to installation the contact surfaces are clean and have not become contaminated or oxidised to such an extent that a good path of continuity cannot be ensured.

6. Commissioning

The following commissioning instructions are in line with clause 7.11 of EN60335-2-69. To commission your product, first check that all packaging and protection materials - such as remote controls taped inside the unit, etc. - are removed prior to start up.

Once these checks have been completed, ensure that the following steps are completed to commission your unit:

- Check that all connections have been correctly made and that the appropriate power sources are available.



WARNING! DO NOT plug, or make connections to, the solenoid valve vent ports as this may inhibit the operation of the valves.



NOTE! Unless otherwise specified, the cleaning control and manifold have been tested to be fully functional on despatch from our works. With the exception of power supply to the controller and fan (if fitted) along with a compressed air supply to the manifold, no other connections are required.

- Check all control functions.
- Ensure all cartridges are correctly fitted.
- Ensure all access doors are sealed.
- Where fans are fitted; adjust the system airflow to the design duty and take static pressure readings, as a basis point for reference and future Thorough Examination and Tests (TExTs). If applicable, reduce the airflow as described in Air Volumes.



WARNING! It is IMPERATIVE that the unit is installed and adjusted to ensure that the stated airflow is not exceeded - excessive air volumes can seriously affect filtration efficiency and element life.

7. Maintenance & Troubleshooting

This chapter provides information pertaining to the maintenance of your product, including inspection and trouble-shooting steps.

Maintenance should be carried out by adequately trained personnel, wearing appropriate PPE. Prior to commencing work, the system to which the filter is attached should be non-operational; all sources of energy must be isolated and locked off; and any compressed air retained in the cleaning system must be drained.

Filtermist Limited offer Service and Maintenance Agreements which ensure that the statutory requirements of inspection and testing are met, with appropriate records. Please contact our team for further information if this may interest you: by telephone on **(0)1952 290500** or by email at **sales@filtermist.com.**

WARNING! DO NOT under any circumstances attempt to work in conditions where appropriate working platforms and access have not been erected, or where personal safety equipment appropriate to the task in hand is not available.

IMPORTANT! When accessing the top of the machine for maintenance and/or planned inspections, due consideration should be given to for working at height, in line with your risk assessment

IMPORTANT! If power tools are required to remove solidified sludge, suitable hearing protection must be worn

IMPORTANT! The operator should take care when carrying out maintenance on this machine and mitigate or eliminate any risks in accordance with clause 7.11 of EN60335-2-69

DANGER! Manifolds MUST NEVER be tested with cleaning valves and other equipment fitted. The manifold must be stripped and blanking plates fitted prior to testing.

7.1. Inspections

7.1.1 Routine Inspection

The following routine inspections should be performed no later than every six months from the date of first operation / in line with your internal risk assessment, whichever is shorter. Specific industries and applications may require more frequent inspection. Inspect the clean air compartment.

- Inspect the clean air compartment
- Check filter cartridges, filter clamps and seals
- Test cleaning cycle of reverse air systems and mechanisms
- Measure and record (a) system airflow volume, (b) pressure differential and (c) static pressure. Record controller settings
- Check fans and motors (where fitted)
- Check doors, cover, and collection bin seals and clamping (where fitted)
- Inspect explosion panels and weather covers (where fitted). The inspection is now complete - tighten the access door securing nuts

IMPORTANT! Do not overtighten access door securing nuts, max torque 22Nm.

7.2. Troubleshooting

If issues with your product occur, consider the following causes prior to calling for a service.

Table 1. Troubleshooting

Fault	Potential Cause
Filter Elements Not Cleaning	Check that the compressed air supply is turned on and that the pressure is as specified. Ensure that filter elements are contaminant free.
	Check that the controller is operating correctly.
	Check the solenoid valve operation.
	Check that the solenoid valve vent ports have not been obstructed or plugged - if they are, clean them out.
	Check diaphragm valve operation.
Dust Deposits On Clean Side	Check filter media for damage - replace damaged media if so.
	Check all seals for damage - repair or replace seals as necessary.
	Check filter element location - correct, if required.
High Differential Pressure	Check cleaning cycle - adjust, if necessary.
	Check that design air volume is not being exceeded - if so, reduce the air volume.
Low Differential Pressure	Check filter media for damage - replace damaged media if so.
	Check your cleaning cycle routine - frequent cleaning cycles may cause low differential pressure. If so, reduce the number of cycles you place the unit through.
	Check for correct fan rotation - alter, if necessary.

7.3. Spare and Replacement Parts

If you require spare or replacement parts for your product, please contact us: sales@filtermist.com or (0)1952 290500.

When ordering replacement or spare parts, or requesting information regarding performance of application, please specify the serial number(s) of the dust collector(s).

8. Declaration of Conformity

<table>
<tr><td colspan="3">EC DECLARATION OF CONFORMITY</td><td colspan="2">FILTERMIST</td></tr>
<tr><td>Manufacturer's name:</td><td>Filtermist Limited</td><td colspan="2">Machinery covered by this declaration:</td></tr>
<tr><td rowspan="3">Full address:</td><td rowspan="3">Telford 54 Business Park,
Nedge Hill,
Telford
Shropshire
TF3 3AL</td><td>Description:</td><td>Dust Collector Unit</td></tr>
<tr><td>Function:</td><td>The extraction, separation, and filtration of airborne dust, particulates, or fumes from an industrial process stream to ensure clean air discharge</td></tr>
<tr><td>Type:</td><td>CFC Series</td></tr>
<tr><td></td><td></td><td>Model:</td><td>CFC1-10-06,CFC1-05-03,CFC1-5-03,CFC3-10-12,CFC2-10-12,CFC5-10-12,CFC4-10-12,CFC1-10-12,CFC 300mm ,CFC 600mm &CFC 1200mm</td></tr>
<tr><td></td><td></td><td>Serial No.:</td><td>All Dustcheck products with 5-digit serial numbers starting from 00001, as per the data plate</td></tr>
<tr><td colspan="5">The machinery conforms to all the requirements of the Machinery Directive 2006/42/EC.</td></tr>
<tr><td colspan="2">The following standards have been used:</td><td colspan="3">EN12100:2010, EN 60204-1:2018, EN ISO 14120:2015, EN ISO 13857:2019</td></tr>
<tr><td colspan="5">The technical file is compiled in accordance with part A of Annex VII of the Machinery Directive 2006/42/EC.</td></tr>
<tr><td colspan="2" rowspan="2">Person authorised to compile the technical file (based in the European Community):</td><td>Name:</td><td colspan="2">Absolent AB</td></tr>
<tr><td>Address:</td><td colspan="2">Staplaregatan 1SE-531 40 LidköpingSweden</td></tr>
<tr><td colspan="5">The relevant authorised person undertakes to transmit, in response to a reasoned request by the national authorities, relevant information on the machinery. This information will be transmitted by: (email, post)</td></tr>
<tr><td colspan="2" rowspan="5">Person authorised to make this declaration:</td><td>Name:</td><td colspan="2">Mark Newman</td></tr>
<tr><td>Position in company:</td><td colspan="2">Operations Director</td></tr>
<tr><td>Signature:</td><td colspan="2"></td></tr>
<tr><td>Place of Declaration:</td><td colspan="2">Filtermist Limited, Telford 54 Business Park, Nedge Hill, Telford, Shropshire, TF3 3AL</td></tr>
<tr><td>Date of Declaration:</td><td colspan="2">1st June 2026</td></tr>
</table>

V2

Only valid if your unit was specified and supplied as an ATEX rated unit

EU Declaration of Conformity (DOC)

We

Company name:	Filtermist Limited
Postal address:	Telford 54 Business Park, Nedge Hill
City	Telford
Postcode:	TF3 3AL
Telephone number:	01952 290500
E-Mail address:	sales@filtermist.com

Declare that this DOC is issued under the sole responsibility of the manufacturer.

Product:	Dust Collector Unit
Type:	CFC Series
Batch:	N/A
Serial number:	All Dustcheck products with 5-digit serial numbers starting from 00001, as per the data plate
Brand Name:	Dustcheck (a subsidiary of Filtermist)

Object of the declaration

To fit to machinery to extract industrial dust & filter to air	

The object of the declaration described above is in conformity with the relevant Union harmonisation legislation:

EMC Directive 2014/30/EC

RoHS Directive 2015/863/EU

ATEX 2014/34/EU

Internal Ex II 2/3D Ex h IIIB T125°C Db/Dc
External Ex II 3D Ex h IIIB T125°C Dc

Atex Certificate No. CML 20ATEXT308

The following harmonised standards and technical specifications have been applied:

Title, Date of standard/specification:

EN IEC 60079-0, EN ISO 80079-36:2016, EN ISO 80079-37:2016, EN 1127-1:2019, EN 14491:2012, EN 61000-6-2:2019, EN 61000-6-4:2019, EN IEC 63000:2018

Additional information:

The relevant authorised person undertakes to transmit, in response to a reasoned request by the national authorities, relevant information on the machinery. This information will be transmitted by: (email, post).

Person authorised to compile the technical file, based in the European Community is: Absolent AB

Address: Staplaregatan 1, SE-531 40 Lidköping, Sweden

Signed for and on behalf of:

Place of issue	yyyy-mm-dd	Name, function, signature
Filtermist Limited, Telford 54 Business Park, Nedge Hill, Telford, Shropshire, TF3 3AL, England	2026-06-01	Mark Newman Operations Director



Only valid if your unit was specified and supplied as a Non-ATEX rated unit

EU Declaration of Conformity (DOC)

We

Company name:	Filtermist Limited
Postal address:	Telford 54 Business Park, Nedge Hill
City	Telford
Postcode:	TF3 3AL
Telephone number:	01952 290500
E-Mail address:	sales@filtermist.com

Declare that this DOC is issued under the sole responsibility of the manufacturer.

Product:	Dust Collector Unit
Type:	CFC Series
Batch:	N/A
Serial number:	All Dustcheck products with 5-digit serial numbers starting from 00001, as per the data plate
Brand Name:	Dustcheck (a subsidiary of Filtermist)

Object of the declaration

To fit to machinery to extract industrial dust & filter to air	

The object of the declaration described above is in conformity with the relevant Union harmonisation legislation:

EMC Directive 2014/30/EC

RoHS Directive 2015/863/EU

The following harmonised standards and technical specifications have been applied:

Title, Date of standard/specification:

EN 60204-1:2018, EN ISO 14120:2015, EN ISO 13857:2020EN 61000-6-2:2019, EN 61000-6-4:2019, EN IEC 63000:2018

Additional information:

The relevant authorised person undertakes to transmit, in response to a reasoned request by the national authorities, relevant information on the machinery. This information will be transmitted by: (email, post).

Person authorised to compile the technical file, based in the European Community is: Absolent AB

Address: Staplaregatan 1, SE-531 40 Lidköping, Sweden

Signed for and on behalf of:

Place of issue	**yyyy-mm-dd**	**Name, function, signature**
Filtermist Limited, Telford 54 Business Park, Nedge Hill, Telford, Shropshire, TF3 3AL, England	2026-06-01	Mark Newman Operations Director



This page is intentionally left blank.

Supplied by:



Certificate Number 1122
ISO 9001
ISO 14001